Contents

Welcome to your OT-S226C

Part name and functions 4
Performing basic functions 6
Menu map 8
Understanding screen icons 10

1. Getting started 12
Installing your battery 12
Caring for the battery 13

2. Making and receiving calls 15
Making a call 15
Answering a call 16
Dealing with missed calls 17
Setting up speed dial 19
Supp. Services 20
Emergency numbers 21

3. Entering letters, numbers, and symbols 22
Text entry modes 22

4. Contacts 26
Saving a phone number 26
Find the contact 27
Viewing memory status 28

5. Messages 28

1. New message 28
2. Inbox 30
3. Outbox 32
4. Draft 32
5. Voice box 33
6. Settings 33
7. Reserved message 34
8. Failed list 34
9. Memory status 35
6. My document 35
1. Picture 35
2. Ring 35
3. Memory status 36
7. Profiles 36
8. Game 37
Game 37
9. FM Radio 37
10. Tools 38
1. Alarm 38
2. Calendar 40
3. Memo 40
4. Calculator 41
5. Stopwatch 41
6. Timers 42

7. Converter 42
8. World time 42
11. Settings 42
1. Security setting 43
2. Call 44
3. Display 45
4. Keystoke setting 46
5. Auto power on/off 46
12. Getting help 47
Customer support 47
13. SAR Information 48

Welcome to your OT-S226C

Part name and functions

Name	Functions
1. Earpiece	Hear voices here during a talk.
2. Display Screen	Display information.
3. Jack	For AC adapter (included).
4. Left soft keys	From the Home Screen, press to enter main menu. Within a menu, press to return to previous display.
5. Send/Receive key	Dials a number or answer a call. Press to view "**Dialed Numbers**" from idle screen.
6. * key	When inputting the number, holding the word to enter P.
7. Right soft keys	From the Home Screen, press to enter contact.

Name	Functions

8. OK or Select key	From the Home Screen, press to enter Main Menu. Within a menu or a function, press to choose a menu or accept an operation.
9. End/Power key	Press to end a call or return to Home Screen. Press and hold to power phone on/off.
10. Navigation Key	4-way navigation for scrolling through lists. Also accesses Shortcuts from the home screen.
11. # key	Press to enter courtesy model from idle screen.

Warning: Inserting an accessory into the incorrect jack will damage the phone.

Performing basic functions

To	From the Home Screen
Switch on the phone	Press and hold the End/ Power key for approximately 3 seconds.

Switch off the phone	Press and hold the End/Power key for approximately 3 seconds.
Make a call	Enter the number using the alphanumeric keypad then press the Call/Send key.
End a call	Press the End/Power key.
Answer a call or Access Outgoing Calls list	Press the Call/Send key.
Verify Own Number	Press the OK key to enter the Menu and scroll to Contacts --> Own Phone Number.
Access SMS	Press the UP Navigation Key.
Mute all sounds	Press and hold the # Key.
Access profiles	Press the LEFT Navigation Key.
Access entertainment	Press the RIGHT Navigation Key.

Menu map

Main menu

FM radio	Recent calls	Tools
Messages	Missed calls	Alarm
New message	Received calls	Calendar
Inbox	Outgoing calls	Memo
Outbox	Call time	Calculator
Draft	Call record	Stopwatch
Voice box	**My documents**	Timer
Settings	Picture	Converter
Reserved message	Ring	City code
Failed list	Memory status	World time
Memory status	**Profiles**	**Settings**
Contact	General	Security
Search by name	Meeting	Call
Add	Outdoors	Display
Search by group	Mute	Keystroke
Speed Dial	**Game**	Auto power on/off

Own number		
Contact management		

Navigating menu

- From the home screen, press the OK key to enter the Menu.
- Use the UP, DOWN, LEFT and RIGHT Navigation Keys to browse through the menus.
- To access soft keys located at the bottom of the display screen, press the DOWN Navigation key and use the LEFT and RIGHT Navigation Keys to select a soft key function. Press the OK key to select a menu or menu item.

- Press the C key or Left soft keys to return to the previous screen.
- Press the End/Power key to return to the idle screen.

Understanding screen icons

These icons may appear on the screen of your phone.

Icon	Description
	The more bars, the stronger the signal.
	Indicate that is talking on the phone.
	You have received one or more text messages
	Indicate that are in general state.
	Indicate that are in outdoors state.
	Indicate that are in meeting state.
	Indicate that are in mute state.
	Indicate that the message box has been full.
	Indicates that you have locked the phone.
	Alarm has been set.

	Battery power indicator. More bars indicate a higher power level.
	Indicates roaming when home network is not available.
	Indicate that using data service.

1. Getting started

Installing your battery

You must install and charge the battery to use your phone. Insert the ridge at the bottom of the battery into the base of the phone, then push the battery down and snap it into place.

Charging the battery

The battery is not fully charged when you purchase your phone. Fully charge the new battery for approximately 12 hours before using the phone for the first time.

To charge the battery, connect the AC adapter to the jack located at the side of the phone, then connect the adapter's plug to an AC wall outlet.

The battery icon at the top-right corner of the screen tells you whether the phone is:

- Charging (animated icon)
- Partially charged

- Fully charged

Recharging the battery

You can safely recharge the battery at any time, even if it has a partial charge.

Caring for the battery

This section describes important safety information and tips for improving battery performance.

General safety guidelines

This phone contains an integrated Li-Ion battery.

- Do not attempt to open the battery compartment and dismantle, puncture, or short-circuit the battery.
- If you have not used the battery for more than a month, recharge it before using your phone.
- Avoid exposing the phone to extreme temperatures, direct sunlight, or high humidity.

- Never dispose of used batteries in or near a fire. It could lead to explosion. Check with your local regulations for proper disposal instructions.

Common causes of battery drain

The following operations drain the battery more quickly and thereby adversely affect talk and standby times:

- Playing games frequently.
- Frequent use of the backlights.
- Using data cables or accessories, such as the Hands-free headset.
- Operating when no service is available, or service is available intermittently.
- High earpiece and ringer volume settings.
- Unacknowledged text message alerts.

Battery performance

	750 mAh (standard battery)
Standby time*	130 hours
Talking time*	120 – 150 minutes

2. Making and receiving calls

Making a call

1. Make sure you are in an area where the signal can be received. Look for the symbol on the home screen.
   Note: The more bars you see in this symbol, the stronger the reception. If there are no bars, try to move to where the reception is better. In some cases, this can be as simple as changing the direction you are facing.
2. Enter the phone number.
3. To dial the number, press the Send/Receive key.
4. To end the call, press the End/Power key.

Redialing a number

To redial the last number called, press the Send/ Receive key twice.

Calling a saved number

If you have already saved a phone number, you can use the Contacts list to find it quickly.

1. Select Menu --> Contacts.
2. Find the contact you want, then press the Send/Receive key to dial the number.
3. If the number has been added to the Speed Dial list, you can dial it directly by holding its Speed Number.

Answering a call

When you receive a call, the phone rings, vibrates, and/or lights up, and an animated phone icon appears. The number of the caller also appears if it is not restricted. If the number is stored in your Contacts directory, the contact name appears.

To answer the call, press the Send/Receive key.
Note: If you have Call Waiting as part of your service, you can answer incoming calls when you are already on a call. When on a call, you will hear a beep tone. Select Answer to put the current call on hold and answer the new call.

Setting the way to Answer a call

1. Select **Menu --> Settings --> Call --> Other --> Answer mode**.
2. Select **any key, Answer key or flip** then press **OK** to confirm.

All incoming calls can now be answered by pressing any key except **END** key, or **OK** key.

Dealing with missed calls

When you have missed a call, “Missed 1 call” appears on your screen.

- To clear the screen, press **OK** key or **End/Power** key.
- To view the caller’s number or name, select recent calls to access the **Missed Calls**.

Viewing recent call details

Details on the last 10 calls you have missed, made or received are stored in the **Recent Calls** list. You can get details on the caller’s name and phone number, along with the time and length of the call.

Viewing recent calls

1. Select **Menu --> Recent Calls**.
2. Select an option from the list: **Missed Calls, Received Calls** or **Outgoing Calls**.
3. To confirm, press **OK**.
4. Select a phone entry, Press **OK** to confirm.
5. Select an option from the list.

Call timer

Your phone includes three timers that count the duration of the calls you have made and received. To view call timers:

1. Select **Menu --> Recent Calls --> Call Time**.
2. Select an option from the list:

- **Received Calls** – The duration of incoming calls received by the phone since the timer was last reset.
- **Dialed Calls** – The duration of outgoing calls made by the phone since the timer was last reset.
- **Total Calls** – The duration of all outgoing and incoming calls since the phone was manufactured.

3. Press left soft key, you can clear the record.

Setting up speed dial

Speed dialing allows you to quickly dial a stored phone number by entering a one-digit speed dialing location. To save a number to speed dial:

1. Select **Menu** --> **Record** --> **Speed Dial**.
2. Select one number and input one phone number then press **OK** to save.

Using 1-Touch Dialing

To dial a phone number, simply press and hold the

assigned speed dial number for the phone number. For example, if the Speed dialing number is 5, press and hold 5.

Supp. services

Let you enable/disable some supplement services provided by your network operator. Consult your local network service provider for more information about these services.

Call Waiting

When Call Waiting is activated, if you are in a call and another call is incoming, there will be an alert and the new calling number will be displayed on the screen. You can choose to answer it or reject it. If the new call is answered, the former one will be hold and you can toggle between the two calls by Send key.

1. Select Menu --> **Settings** --> **Call** --> **Supp. Services** --> **Call Waiting**.
2. Select an option from the list.
   On: Open the Call Waiting

Off: Close the Call Waiting
To voice mail number: Forwards to the voice mail number.

3. To confirm, press **OK**.

Call Forwarding

To forward your calls to another phone number:

1. Select **Menu --> Settings --> Call --> Supp. Services --> Forward** as some condition.
2. Enter the number you wish to forward all your calls to.
3. To confirm, press **OK** twice.

Emergency numbers

Calling emergency numbers

You can call all three-digit emergency numbers even if your phone is locked or your account is restricted. However, when you call, your phone enters **Emergency** mode.

3. Entering letters, numbers, and symbols

You may enter letters, numbers, and symbols in the Contacts, SMS and other menu functions.

Text entry modes

There are fore text entry modes:

Ab
En
123
T9
T9PIN

Note: The mode you start in depends on the task you are performing. For example, when entering a phone number in the Contacts menu, the default text mode is Numbers. When entering a name for a contact, the default text mode is the Input Mode.

Entering numbers

To enter a number while in Numbers mode, press a

number key once.

To enter a number while in Multitap mode, press a number key more times until the number appears on the screen.

Entering words letter by letter

Thai mode and Ab mode:

1. Press the appropriate alphanumeric key once to display the first letter that appears on the keypad, twice for the second letter, and so on.
2. Wait for the cursor to move to the right before you enter the next letter.

You can enter the Thai words or English words.

Entering words quickly

T9th mode and En mode:

When you press a series of keys using the mode, it checks the built-in dictionary for common words and predicts the word you are trying to spell.

1. For each letter of the word you wish to spell, press the appropriate alphanumeric key once. For example,

to enter the word “any” press the alphanumeric keys **2 --> 6 --> 9**.

2. If the word suggested by this mode does not match what you want, press the UP or DOWN Navigation Key to view other word matches.
3. When you see the word you want, to confirm your choice press **OK**.

Changing input modes

While in any text editor do the following, hold the # key to change input modes.

Quick reference to text entry

This table gives general instructions for entering letters, numbers.

To	Do this
Enter a letter	Press the appropriate alphanumeric key repeatedly until the letter you want appears on the display.

Enter a number	Press and hold the appropriate number key until it appears on the display. If you are in Numbers mode, then press the number key once.
Erase a character	Press right soft key.
Erase all characters	Press and hold right soft key.
Move the cursor right or left	Use the RIGHT or LEFT Navigation Keys.

4. Contacts

The Contacts menu of your phone is like a set of phone index cards for you to store information about a person or a company.

Saving a phone number

To save a phone number, do the following:

1. From the home screen, enter the phone number you wish to save.
2. Press the Left soft key to select Add to. You can choose the position.
3. Enter the name of the contact then press OK.
4. If you choose add to the phone, you can record others. For example: 4 numbers, email, URL, Momo, make the group.

Adding a pause

When you save the phone number of an automated service, you may include a pause where you need to select an option or enter a Password. You can enter

multiple pauses in a phone number. A Pause will cause the phone to stop dialing until you select the Release key. To enter a phone number with a pause:

1. Enter the first portion of the phone number.
2. Press * Key, a letter P will appear at the end.
3. Enter the remaining part.
4. Save the number. (See “Saving a phone number if needed”).

Find the contact

1. Select **Menu --> Contacts**.
2. Select **search by name, search by group**. You can find the contact quickly.
    - **Search by name:** Input the name, then press OK to view.
    - **Search by group:** View the record according the group.

Viewing Memory Status

1. Select **Menu --> Contacts --> Contact Management --> Memory Status**.
2. Press OK to view the memory status of Phone or UIM card.

5. Messages

This chapter describes how to send, receive, and erase text messages from your phone.

Important: The features and menus described in this chapter may vary depending on services available in your area. In addition, usage charges may apply to each message. For clarification on these issues, check with your service provider.

1. New message

You can edit the message.

When text is OK, press OK key to enter “Send to” display. You can enter phone numbers manually with numeric keys.

Or

Press Left Soft key to select number from the phonebook.

When entering texts, press Right Soft Key to pop up the submenu, you can do:

Send	Send the message.
Copy	Use Left/Right Keys to move the cursor. Press left soft key to the select the start and end of the texts you want to copy. Then move the cursor to select the texts, which are highlighted in black.
Paste	Use Left/Right Keys to move the cursor to where you want to paste the copied texts and press left soft key to execute it.
Cut	Use Left/Right Keys to move the cursor to the start of the texts you want to copy and press OK key to confirm it. Then move the cursor to select the texts, which are highlighted in black.
Delete	Use Left/Right Keys to move the cursor to the start of the texts you want to copy

	and press OK key to confirm it. Then move the cursor to select the texts, which are highlighted in black. Press OK key at the end of the texts. The selected texts are deleted.
Phrase	You can choose to insert Polish phrase, English phrase or Expressions.
Insert number	Insert numbers from the phone book.

Note:

1. Press the number key to select the corresponding function in the submenu directly. E.g.: if the submenu has pop up, press “7” to select an expression.
2. If the message editing is interrupted by incoming calls, alarm clock, press power key or power off, the entered texts will be saved temporally. Next time you enter “Create message”, the phone will ask you if edit unsaved message? If you select “no”, the last edit will be discarded.

2. Inbox

Select and press OK key to enter Inbox.

The messages in the Inbox are displayed. Press right/left key to view inbox. Use Up/Down key to select the message, and then press OK key to view its detail. Use Up/Down key to scroll the texts.

When reading the message, you can:
Press Send key to dial the number directly.
Press OK key to reply a message. Please refer to “Create message” for detail.
Press Right Soft key to pop up the submenu. You can:

1. Reply: Replay this message;
2. Forward: Edit and forward this message;
3. Save to: Save this message to phone or UIM card;
4. Get number: Get the message’s phone number out and then edit it;
5. IP dial: Make a IP call for this number;
6. Lock/unlock: Lock or unlock the message;
7. Set as blacklist: You can set this number as call rejection or SMS rejection;
8. Delete: You can delete currently message; select some messages to delete, delete by number, or delete all.

3. Outbox

Select and press OK key to enter Outbox.

The messages in the Outbox are listed. Use Up/Down key to select the message, and then press OK key to view its detail. Use Up/Down key to scroll the texts. Press Left/Right key to view border upon messages.

When reading the message, you can:
Press OK key to send this message.
Press Right Soft key to pop up the sub menu.

4. Draft

Select and press OK key to enter Draft.

The messages in the Inbox are displayed. Use Up/Down key to select the message, and then press OK key to view its detail. Use Up/Down key to scroll the texts. Press Left/Right key can view border upon message.

Press Right Soft key to pop up the submenu. You can:
1. Forward: Edit and forward this message;
2. Save to: Save this message to phone or UIM card;

3. Lock/unlock: Lock or unlock the message;
4. Delete: You can delete currently message; select some messages to delete, or delete all.

5. Voice box

You can select 1. Listen to voice message, 2. Delete voice mail, 3. Set voicemail number.

6. Settings

Select to enter SMS settings.

1. Prior memory area

You can select place the message in phone or RUIM card.

2. Message validity

Let you select from 12 hours/1 day/1 week/ Maximum as the validity period for your sent message.

Your message is sent to the network first, and then

forwarded to the recipient if his phone can be accessed. Validity period is a time period, after which the network will delete the message automatically without sending it when the recipient's phone keeps inaccessible, for example powered off or with Inbox fulfilled.

7. Reserved message

Select and enter reserved message.

You can create messages, edit reserved SMS, or view failed reserved message.

When the reserved time has arrived, the phone will register to send the message.

8. Failed list

Let you view the report of last send message.

If one number is failed, press OK key to send the message again.

9. Memory status

Select “Memory status” and press OK key to enter.

The current message quantities and remaining capacity of Phone, Inbox, Draft, Outbox and card are listed.

6. My document

From idle screen, press OK to view main menu and select My document.

You can view the user, the record in the My data, Picture, Ring, Other files, Memory status.

1. Picture

From Explorer menu, select “Picture” to view picture files concluded. Press OK key to view the selected picture, press Left Soft key to pop out submenu.

2. Ring

From Explorer menu, select “Ring” to view music concluded. Press OK key to play the selected file, press Left Soft key to pop out submenu.

3. Memory status

From Explorer menu, select “Space Info” to view some detailed information about the memory.

7. Profiles

You can set the state according to the circumstance.

Select and enter profiles.

The profiles include four types: General, Meeting, Outdoors, Mute.

Press left soft key to pop up the submenu. You can:

1. Start: You can choose one type and start the profile.
2. Personalize: You can set Call ringtone, Message tone, Reserved SMS tone, Alert tone and other according to you like.
   Eg: Select and enter the call ringtone, press up and down key to select to set ringtone or volume, press right or left key to view all rings or accommodate the volume.
3. Default: Resume the current profile to the default patter. Press “yes” to save the settings.

8. Game

Game

You can play Gobang, Shove it or Dice.

The detail you can view the game help.

9. FM radio

You can use the phone as the FM, when insert the earphone.

Press left and right Directional keys to accommodate the channel.

Call out Sub Menu with Right Soft key, you can do something about the FM.

10. Tools

You can use some tools set on the phone.

Press Left soft key from idle display to view Main Menu, select tool and press OK to view it.

1. Alarm

When in PIM menu, scroll to Alarm and press OK to select it.

The alarm list is displayed. Up to 6 alarms can be set. The set alarms can still function when the phone is powered off.

Scroll to one alarm and press OK to edit it.

Set alarm time

Move the prompt to the item (hour/minute) you want to edit with **Left/Right keys** and input alarm time directly with Numeric keys, press **OK** key to save the edit.

Set alarm mode

You can set the alarm to function daily, weekly or on Specify date. When setting designated alarm date, use Multi Directional keys.

Select ringtone

You can select the ringtone.

Press **OK** key to confirm it. Choose one alarm state and press **OK** key to confirm it.

The alarm is set and saved.

Note:

1. The alarm volume is the same as the current ringtone volume. If the phone is set to vibration only, the alarm vibrates only.
2. When in alarm list display, scroll to one alarm and press Right Soft key to clear its settings directly. Or you can press OK key to select it and then press Right Soft key to clear its settings.

2. Calendar

When in PIM menu, scroll to calendar and press **OK** to display Schedule menu.

Press the **Multi-Directional keys**, the cursor will move towards the corresponding direction. Press *key and # key enter to last month and next month.

Press Right Soft key to pop up the submenu. You can:

1. View	View the arrangement this day.
2. Add event	Add new event for this day.
3. Reserve msg	Edit reserve message.
4. Delete	Delete the calendar this day, this month or all.
5. Memory status	Display all calendar arrangement.
6. Settings	Can set the start and end time, and set auto delete.

3. Memo

You can set Text memo and Voice memo.

Select and enter text memo.

The non-blank note appears with the beginning of contents, or only “note” appears. You can press Right Soft key to delete one selected note directly.

Select one note and press **OK** to view it. Press **OK** again to edit it. Press **Right soft key** to delete it.

4. Calculator

When in PIM menu, scroll to Calculator and press **OK** to do arithmetic.

Multi-directional keys are responding to “+”, “-“, “*”, “/” respectively. Use Right Soft key to set number positive or negative. Use “*” key to input decimal. Press OK key to generate result. Use “#” key to clear all. Press Left soft key to return to PIM menu.

5. Stopwatch

From PIM menu, select Stopwatch and press **OK** key to display the stopwatch interface.

Press **OK** key to start the watch, press **OK** key again to

stop it, press **Right Soft key** to clear.

6. Timer

You can set time to awake some things.

7. Converter

You can conversion some unites.

8. World time

From PIM menu, select World Time and press OK key to view local time for some cities around the world.

A world map is displayed. Press Left/Right key to move the square icon which represents the city's location. The city's name and local time are displayed below.

11. Settings

Select settings in the main menu, you can do some settings following your need.

1. Security settings

Security item

You can select and set Message, Phonebook, or call history.

Phone lock

You can set the phone lock as on or off.

Change password

Input your old password first, then input new password, then input new one again to confirm it.

PIN check

You can set the PIN check as on or off.

Change PIN

You can change the PIN code.

Restore factory settings

Reset all settings to be those of coming out of factory. The phone's password will be needed.

After resetting, the phone will power off automatically. When the phone is powered on again, all settings has been reset.

2. Call

Call rejections

You can set 10 reject number, you can reject these number calling.

Msg. rejections

You can set 10 reject number, you can reject these number messages.

Supply services

Let you enable disable some supplement services provided by your network operator. Consult your local network service provider for more information about these services.

Other

Select and enter to other.

You can set Answer mode, Alert on call, Auto redial, Auto answer.

3. Display

Language /style/ themes

You can choose the language as English or Thai.

And set the Style and themes of the interface.

Backlight

You can choose the backlight as 5sec, 10sec, 20sec,

30sec.

Standby

You can set the wallpaper.

And setting the carrier information and time display as on or off.

4. Keystoke settings

Shortcut

You can set that pressing the Multi-Directional keys to enter some menu from idle display.

Backlight

You can set the backlight on or off, and set the start and end time.

Auto key lock

You can select to turn on or off the auto key lock.

5. Auto power on/off

Let you Set auto power on / off. When set as on, you can set the time.

12. Getting help

Customer support

Your service provider's customer support department may be accessible directly from your phone when you dial a number (check with your service provider). They can answer questions about your phone, phone bill, call coverage area, and specific features available to you, such as call forwarding.

Before requesting support, please try to reproduce and isolate the problem. When you contact the Customer Care Center, be ready to provide the following information:

- The name of your service provider.
- The actual error message or problem you are experiencing.

- The steps you took to reproduce the problem.
- The phone's electronic serial number (ESN).
- To find the ESN:
  a) Remove the battery.
  b) Locate the white label on the back of the phone. Your phone's ESN is located on the label.

13. SAR information

THIS MODEL PHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. * Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use at the ear is 1.32 mW/g and when worn on the body is 1.5 mW/g. While there may be differences between the SAR levels of various phones and at various positions,

they all meet the government requirement for safe exposure.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of http://www.fcc.gov/oet/fccid after searching on XXXXXXXXX.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) web-site at http://www.wow-com.com.

* In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Contact us: www.catcdma.com

CAT call center: 1322

Alcatel call center: 0-2642-1884

Alcatel logo and Alcatel name are Trademark of Alcatel-Lucent used under license by TCT Mobile Limited

All rights reserved © Copyright 2008 TCT Mobile Limited

TCT Mobile Limited reserves the right to Alter material or technical specification without Prior notice.